

Fitting Instructions

Defender 300Tdi/Td5 Raised Air Intake



Note - 5 items in kit

1. Remove the offside plastic air intake grill.
2. Remove the plastic fixing plugs from the wing and replace with the spring nuts provided.
3. Fix the base plate to the wing using the foam washer and existing screws.
4. Remove trim from the inside of the windscreen pillar.
5. Assemble the flexible pipe onto the base pipe and inset the long tube into the flexible pipe with the curve at the top.
6. Mark and drill the 5.5mm holes for the angle brackets on the windscreen pillar -
 - One should be in line with the gutter rail of the windscreen
 - The other at the top of the straight section of the tube.
7. Bolt the brackets to the windscreen frame using the nuts and bolts and foam washers provided.
8. Clamp the tube to the brackets using the 2 rubber lined clamps.
9. Place large washer onto the top of the main tube, hold the remaining clamp over the flange of the mushroom head and position over the large washer on the main tube and then tighten the clamp.
10. Fix the two plastic large clips to the flexible pipe.