

Defender Wheel Arches

BRITPART

The quality parts for Land Rovers

FITTING INSTRUCTIONS

Part Number - DA2366



The arches will fit in one correct position - from bottom of door (sill). However if you want them higher they can be placed where you would like.

Position the arch and mark the body or wing with a felt tip and cut the wing just above the line. It is not necessary to cut the body unless you are exceeding a 33" tyre size. You may want to paint the body black if you are not cutting out below the arch, this does look better but it is your choice.

Push the rubber sealing strip onto the arch then mark and drill a 2mm hole through the body and arch. Screw up using the screws and caps for a smart finish.

If you drive in severe off-road conditions you can cut out the inner edge (10mm from the top edge) for even more flexibility.

Disclaimer

These fitting instructions are intended for general guidance only. No responsibility will be accepted for damage to persons, property, equipment or vehicles caused during or arising from the fitment or using of this product. Fitting this item to your vehicle may constitute a vehicle modification and therefore we strongly recommend that you check the product complies with local laws and legislation and always inform the vehicle's insurance company accordingly. Vr. 1.

