



L.O.F POWERspring Pedal Assist Kit Fitting Instructions

****Disclaimer 1** – The U shaped bush as fitted to the Discovery 1 is wider than the one supplied in the LOF kit, (Part is no longer available) We suggest reusing the old LR bush, but we have supplied the Defender bush in the kit also, so if needed you can use an abrasive pad to thin the pedal allowing the Defender bush to be used!

****Disclaimer 2** – Take care not to break the U shaped bush supplied, although this is a Genuine LR part, it is injection moulded and is easily damaged! (if you break the bush please email us and we will post one out free of charge)**

****Warning** – Take care not to break the U shaped bush supplied, although this is a Genuine LR part, it is injection moulded and is easily damaged!

Wedge the pedal down to the floor using a piece of wood/metal bar
(Perfect length is 50cm)

Remove any existing coil spring or original over centre type spring.