

Now use another pair of mole grips to retain this side of the spring to stop it moving.



Now grip the other side of the spring and push it into the bush hole - on this side we prefer to pull the spring from the bottom of the footwell into place.

Once the spring is fitted into all 3 bushes, make sure it is seated centrally. If the pedal box 'tabs' are spread wide apart, they can be bent inwards to give a tighter fit as shown! (Pedal boxes are varying in dimension due to fabrication tolerances).

