

# Discovery 2 Towing Kit

#### IN THE BOX

- A 1 x Main Bar
- B 2 x Handed Side Arms

#### IN THE FITTING KIT

- C 2 x M14x90 Bolts & Spring washers
- D 4 x M12x35 Bolts, Nuts & Washers
- E 2 x M16x110 Bolts, Nuts & washers
- F 2 x M16x50 Bolts, Nuts & Washers

1. Attach A to underside of cross member of vehicle using C.
2. Bolt B to A using D and to the chassis using E. Tighten all bolts.

Finally using F fit ball and wiring kit (not supplied with this kit). Fully tighten.

This towbar must be used with a type approved ball conforming in A50-1 dimension with adequate D & S values.

