

## Fitting Notes



- > Undo the lower panhard rod bracket bolt which passes through the chassis.
- > Undo the lower two bumper mounting bolts.
- > Loosely fit the four mounting bracket to plate screws.
- > Offer up the guard and hold in position
- > Replace the two lower bumper mounting bolts so that they also pass through the corresponding steering guard bracket.
- > Replace the lower panhard rod bracket bolt so that it passes through the corresponding steering guard bracket.
- > Use the new bolt provided for the last remaining mount hole and pass through the corresponding chassis location.
- > Tighten all of the bracket to chassis bolts.
- > Tighten all four of the steering guard bracket to plate screws.