

## Important

### Please read this fully before fitting the kit

Thank you for purchasing a Britpart re-trim kit.

A complete Britpart re-trim kit should include:

- 1 x Can of Contact Adhesive Spray
- 1 x Cushion Foam
- 1 x Squab Foam
- 1 x Cushion Cover
- 1 x Squab Cover
- 6 x Plastic Nails
- 1 x Metal Rods
- 1 x Rubber Retainer

If any of the above parts are found to be missing from your kit please contact your supplier.

**WARNING:** All aspects of health and safety should be observed while fitting this part and Britpart will not be held responsible for any injury caused during the installation or use of this kit. The included Contact Adhesive Spray must only be used in a well ventilated area and the instructions on the can should be read fully before commencing.